

## NOTICE DE MONTAGE

### **CAPOT DE SELLE ERMAX ADAPTABLE SUR YAMAHA MT 125 2014 → ∞** Durée estimée de montage : 15mn



#### Kit de fixation

- 1 entretoise plastique Ø ext. 20 mm Ø int. 10 mm largeur 10 mm
- 1 écrou borgne noir M8
- 1 rondelle acier Ø8 type L
- 1 vis BHC 8x20

#### Montage

- Déposer la selle d'origine
- Monter le capot de selle en intercalant l'entretoise plastique entre la fixation de la moto et le capot comme indiqué sur la photo ci-contre :



Entretoise plastique

- Fixer le capot avec l'écrou borgne noir M8 sur la tige fileté devant et avec la vis BHC Ø8 sur le dessus.

#### « ATTENTION »

- \* Les pièces peintes et vernies ne sont pas garanties contre les lavages vapeur « haute pression » ou les produits nettoyants agressifs qui peuvent les endommager et décoller le vernis. Nous conseillons d'ailleurs, d'après les données techniques de nos fournisseurs en peinture, d'attendre un mois afin d'obtenir une polymérisation complète du vernis.
- \* Tout accessoire monté ne sera plus considéré comme neuf et ne sera **ni repris ni échangé**.
- \* Les accessoires Ermax sont conçus pour des **montes d'origine**. Ils ne seront pas garantis s'ils sont utilisés dans d'autres conditions.
- \* En raison des tolérances de fabrication des véhicules, indépendantes de notre volonté, certains produits Ermax peuvent nécessiter des ajustements lors de la fixation.
- \* Les marques de fabricant de motos citées sont indiquées exclusivement comme référence nécessaire à la destination des accessoires Ermax.
- \* Attention aux serrages excessifs qui pourraient abîmer ou casser nos accessoires en plastique et les vis en aluminium.

## FITTING INSTRUCTIONS

**ERMAX SEAT COVER**  
**ADAPTABLE ON YAMAHA MT 125 2014** → ∞  
Estimated fitting time : 15mn



### Fitting kit

- 1 plastic spacer Ø ext. 20 mm Ø int. 10 mm width 10 mm
- 1 black blind nut M8
- 1 steel washer Ø8
- 1 screw BHC 8x20

### Fitting instructions

- Remove the original passenger saddle.
- Place the seat cover by inserting the supplied plastic spacer between the fixation of the motorcycle and the seat cover as shown on the picture :



Plastic spacer

- Fit the cover with the black blind nut M8 on the threaded bracket on the front, and the screw BHC Ø8 on top.

#### « CAUTION »

- \* Painted and varnished parts are not guaranteed against high pressure steam washes or aggressive cleaning products which can damage them and unstuck the varnish. We advise moreover, according to the technical data of our painting suppliers, **to wait one month** to obtain a complete polymerization of varnish.
- \* Accessories gone up on the motorbike will not be any more considered as new and will be **neither retaken nor exchanged**.
- \* Ermax accessories are foreseen for **original equipments**. They will not be guaranteed if they are used in others conditions.
- \* Due to vehicles made tolerances, beyond our control, some Ermax products might need adjustments to fit.
- \* The mentioned label of motorbikes's manufacturers are indicated exclusively as a reference to Ermax accessories.
- \* Care to excessive clampings which may damage or break our plastic accessories and aluminium screws.