



1074, Avenue des Carrières – Z.A la Plaine du Caire III
13830 ROQUEFORT LA BEDOULE – FRANCE
www.ermamax.fr - e-mail : accueil@ermamax.fr

NOTICE DE MONTAGE

ECOPES DE RADIATEUR ERMAX ADAPTABLES SUR KAWASAKI Z 750 N 2004/2006

Kit de fixation

- 2 entretoises Ø6, longueur 5mm (pour les écopés Z750 look Z1000 uniquement).
- Grilles aluminium (en option pour les écopés Z750 uniquement : elles se placent au niveau des entrées d'air avec de la colle à pare-brise (colle polyuréthane)).

Montage (pour les écopés Z750 look Z1000 uniquement)

- Démontez les écopés du radiateur d'origine.
- Positionnez les écopés fournis en insérant l'entretoise entre le radiateur et l'écope au niveau du point de fixation supérieur.
- Maintenez l'ensemble à l'aide des vis d'origine en faisant attention de ne pas serrer excessivement pour ne pas endommager la pièce.

« ATTENTION »

* Les pièces peintes et vernies ne sont pas garanties contre les lavages vapeur « haute pression » ou les produits nettoyants agressifs qui peuvent les endommager et décoller le vernis. Nous conseillons d'ailleurs, d'après les données techniques de nos fournisseurs en peinture, d'**attendre un mois** afin d'obtenir une polymérisation complète du vernis.

* Tout accessoire monté ne sera plus considéré comme neuf et ne sera **ni repris ni échangé**.

* Les accessoires Ermax sont conçus pour des **montes d'origine**. Ils ne seront pas garantis s'ils sont utilisés dans d'autres conditions.

* En raison des tolérances de fabrication des véhicules, indépendantes de notre volonté, certains produits Ermax peuvent nécessiter des ajustements lors de la fixation.

* Les marques de fabricant de motos citées sont indiquées exclusivement comme référence nécessaire à la destination des accessoires Ermax.

FITTING INSTRUCTIONS

ERMAX AIR INTAKE COVER ADAPTABLE ON KAWASAKI Z 750 N 2004/2006

Fitting kit

- 2 Ø6 spacers, length 5 mm (for air intake cover Z750 look Z1000 only).
- Aluminium nettings (in option for air intake cover Z750 only : they take place at the air intakes with stick for windshield (polyurethane stick)).

Assembly (for air intake cover Z750 look Z1000 only).

- Remove the original air intake covers.
- Place the furnished parts inserting 1 spacer between the radiator and the air intake cover at the upper fitting's level.
- Fix everything using the original screws by paying attention not to screw excessively not to damage the part.

« CAUTION »

* Painted and varnished parts are not guaranteed against high pressure steam washes or aggressive cleaning products which can damage them and unstuck the varnish. We advise moreover, according to the technical data of our painting suppliers, **to wait one month** to obtain a complete polymerization of varnish.

* Accessories gone up on the motorbike will not be any more considered as new and will be **neither retaken nor exchanged**.

* Ermax accessories are foreseen for **original equipments**. They will not be guaranteed if they are used in others conditions.

* Due to vehicles made tolerances, beyond our control, some Ermax products might need adjustings to fit.

* The mentioned label of motorbikes's manufacturers are indicated exclusively as a reference to Ermax accessories.