

# SENSORS

Bezeichnung	Frequenz	Stationen
TX2-D	433 MHz	WS 7013, WS 7014, WS 7032, WS 7042, WS 7050, WS 7073, WS 7079,
TX2-P	433 MHz	WS 7108, WS 7206, WS 7207, WS 7208, WS 7394, WS 7408, WS 8118,
TX16	433 MHz	WS 9117, WS 9150, WS 9151, WS 9210, WS 9310, WS 9611, WT 513,
TX17	433 MHz	WT 531, WT 543, WT 553, WT 572
TX3-C/ TX3-P	433 MHz	WS 7016
TX3-TH	433 MHz	WS 9520, WS 9228, WS 9232, WS 8610, WS 7078, WS 7390, WS 9115
TX4-433	433 MHz	
TX4-868	868 MHz	WS 868015, WS 868025
TX18	433 MHz	WS 3500
TX20 (Windsensor)	433 MHz	WS 2300, WS 2307
TX21-IT	868 MHz	WS 9032-IT (auch TX29DTH-IT)
TX22 (1600-25)	868 MHz	WS 1600-IT
TX23 (Windsensor)	868 MHz	WS 1600-IT
TX24-IT	868 MHz	WS 9004-IT
TX25-IT	868 MHz	WS 8301-IT
TX26 (Regensensor)	868 MHz	WS 1600-IT
TX27-IT	868 MHz	WS 9720-IT
TX27TH-IT	868 MHz	WS 9620-IT
TX29-IT	868 MHz	MA 10430, WS 7014-IT, WS 7394-IT (bis 6N11), WS 9117-IT, WS 9122-IT, WS 9162-IT, WS 9611-IT, WS 9723-IT, WS 9750-IT, WS 9756-IT
TX29DTH-IT	868 MHz	MA 10410, MA 10901, MA 10920, WS 9624-IT, WS 7018-IT, WS 9040-IT, WS 9032-IT
TX35-IT	868 MHz	WD 450, WD 1080, WD 1120, WD 1202, WD 1800, WD 2101, WD 2102, WD 2900, WD 4000, WD 4001, WD 4002, WD 4003, WD 4025, WD 4026, WD 4930, WD 6000, WD 6003, WD 6005, WD 9530, WD 9535, WD 9550
TX35DTH-IT	868 MHz	WD 4204, WD 4910, WD 4920, WD 9000, WD 9245, WD 9542
TX37-IT	868 MHz	WS 9632-IT, WS 8118-IT, WS 8117-IT, WS 9140-IT, WS 9130-IT
TX38-IT	868 MHz	WM 5012, WM 5412
TX38WD-IT	868 MHz	WD 1070, WD 4005, WD 4008, WD 9565
TX40-IT	868 MHz	WS 9215-IT, WS 9245-IT, WS 9136-IT
TX45-TH	868 MHz	WS 9257-IT, WS 9273-IT, WS 9274-IT
TX47-IT	868 MHz	WL 2000
TX51-IT	868 MHz	MA 10450
TX48WD-IT	868 MHz	WD 4012, WD 4017
TX56 (Windsensor)	868 MHz	WS 2800-IT
TX57 (Regensensor)	868 MHz	WS 2800-IT
TX59 (Thermo-Hygro)	868 MHz	WS 2800-IT
TX62-IT	868 MHz	WS 6010-IT
TX70DTH	433 MHz	WS 6750, WS 6760, WS 6765
TX80	433 MHz	WS 6710
TX80-TH	433 MHz	WS 6730, WS 9480
TX96/ TX96-TH	433 MHz	WS 6812, WS 6832, WS 6720, WS 9118 (ab 5N11)
TX96(TW004)	433 MHz	WS 6810, WS 6820, WS 6830
TX104	433 MHz	WS 9135, WS 9170, WS 9180
TX105	433 MHz	WS 6840
TX105TH	433MHz	WS 7060
TX108	433 MHz	WS 9250, WS 9251, WS 9260, WT 529
TX108DTH	433 MHz	WS 8011, WS 9252
TX110-Pool	433 MHz	WS 9005-Pool
TX173, TX174, TX175	433MHz	WS 1700
TX205	433 MHz	WS 9175
TX205-DTH	433 MHz	WS 9065
TX302	433 MHz	WS 6501
TX303	433 MHz	WS 6502
TX643	433 MHz	WT 643
TX960	433 MHz	WS 9767, WS 6870
TX960-TH	433 MHz	WS 6449, WS 9490
TX5000	433 MHz	WM 5200
TX5003	433 MHz	WM 5300
TX6600-1	433 MHz	WS 6600, WS 6620
TX6600-2	433 MHz	WS 6650
TX6600-3	433 MHz	WS 6740
TX6610	433 MHz	WS 6610
TX9006 (Regensensor)	433 MHz	WS 9006
TX9007	433 MHz	WS 9007
TX9116	433 MHz	WS 9116
2300-15 (Windsensor)	433 MHz	WS 2300, WS 2307
2300-16 (Regensensor)	433 MHz	WS 2300, WS 2307
2300-25 (Thermo-Hygro)	433 MHz	WS 2300, WS 2307

# SENSORS



KS 300



KS 550



TX 104



TX 105



TX 108



TX 108-DTH



TX 110-Pool



TX 16



TX 17



TX 18



TX 21-IT



TX 24-IT



TX 25-IT



TX 27-IT



TX 29-IT



TX 29DTH-IT



TX 2-D



TX 2-P



TX 302



TX 303  
TX 6600-3



TX 35-IT



TX 35DTH-IT



TX 37-IT



TX 38-IT  
TX 38WD-IT  
TX 38HC-IT



TX 3-P  
TX 3-C

# SENSORS



TX 3-TH



TX 4-433  
TX 4-868



TX 40-IT



TX 45-IT



TX 5000



TX 5003



TX 62-IT



TX 643



TX 6600  
TX 6610  
TX 6600-1  
TX 6600-2



TX 70-DTH



TX 80



TX 80-TH



TX 90



TX 9006



TX 9007



TX 9116



TX 95-TH-433  
TX 95-TH-433-IW001T  
TX 95-TH-868



TX 96-TH (TW003)



TX 96 (TW004)



TX 960



TX 26

TX 23

TX 22



WS2300-16

TX 20/  
WS2300-15

WS2300-25



TX 57

TX 56

TX 59